



Please read this Manual carefully before use, and properly keep it for reference.

DRONE EXPLORER CAM I INSTRUCTION MANUAL




1. CONTENT OF THE BOX




2. TRANSMITTER

2.1 - Introduction of Transmitter




2.2 - Install Batteries




3. PREPARATION BEFORE FLIGHT

3.1 - Select the flight environment




4. INSTALLATION OF ACCESSORIES

4.1 - Installation and disassembly of phone holder




5. CHARGING THE LITHIUM BATTERY




6. OPERATIONAL GUIDELINES


6.1 - Startup program




6.2 - Shutdown program



6.3 - Trimming




6.4 - Factory Reset




7. OPERATION AND CONTROL


7.1 - Speed threshold switching method




7.2 - Basic action operating method




8. AEROBATICS



9. HEADLESS MODE



10. REPLACEMENT OF FAN BLADE



11. SAFETY NOTES

- Keep away from obstacles. This product is suitable for outdoor flight. The obstacle-environment shall be avoided in order to prevent collisions with any person or other objects and thus damage the drone.
- Keep away from damp and hot environment. The drone consists of many precise electronic elements. Therefore, moisture, high-temperature exposure and other impacts must be avoided, so as to avert any damage to the electronic elements.
- Use safety of lithium battery. It is prohibited to refit or use other lithium batteries for flight. The lithium batteries produced by different manufacturers differ a lot in terms of internal configuration. Otherwise, it will damage relevant electronic elements or even endanger the personal safety. It is prohibited to charge with other chargers (except the original), so as to avoid short circuit, expansion, deformation, fire, explosion and other risks.
- Use safety of NiMH battery. It needs to confirm the position of positive/negative electrode while installing the battery of the remote control. Old and new batteries cannot be mixed, so as to avoid any impact on the service life. If this product will not be used for a long period of time, please take out the battery to avoid leakage and fault. In case of any leakage of the battery, please do not use again.

12. TROUBLESHOOTING

Issue	Cause	Solution
The drone has no response.	1. Unsuccessful pairing 2. Low voltage of the drone or the transmitter.	1. Pair again. 2. Replace the battery of the transmitter. 3. Recharge the drone.
Failure to take off	1. Wrong assembly of the fan blade 2. Deformation of the fan blade after calibration. 3. The LED light of the drone is lit.	1. Check the part of fan blade installation in the specification. 2. Strengthen or reduce the fan blade. 3. Low-voltage protection or recharge the drone.
Shaking of the drone	1. Deformation of the fan blade after calibration. 2. Offset of the gyroscope.	1. Strengthen or replace the fan blade after calibration. 2. Check the part of gyroscope calibration in the specification.
Delayed response or interrupted signal of the drone	Low voltage of the remote control.	Replace the battery of the transmitter.
The drone cannot hover.	The gyroscope is not calibrated.	Calibrate the gyroscope according to the specification.